

IntelliBox IP menu

- 50 *Network setting*
 - 01 Static / DHCP
 - 02 IP Adress (always port 4001)
 - 03 Subnet mask
 - 04 Gateway
 - 05 DNS 1
 - 06 DNS 2
 - 07 MAC adresse port steed

- 51 *Network permission*
 - 01 Allow to change network settings
 - 02 Allow to change input settings
 - 03 Allow to make test shot
 - 04 Allow to blocking mode
 - 05 Allow to flash load and reboot
 - 06 Allow to change password
 - 07 Allow to add new machine and delete machine
 - 08 Allow to make change in this menu

